

# 1 BOSCH EDC17C64 IROM TC1797 EGPT VAG



## 1.1 PLUGIN 1238: NEW TRASDATA

## 1.2 CONNECTIONS

### 1.2.1 EGPT CONNECTION

The following cables must be used to communicate correctly with the ECU:



| WIRE COLOUR                                                                         |       | DESCRIPTION |
|-------------------------------------------------------------------------------------|-------|-------------|
|  | Red   | +12 V       |
|  | Black | GND         |
|  | Green | CAN L       |
|  | White | CAN H       |
|  | Grey  | GPT0        |
|  | Blue  | GPT1        |



### ATTENTION

For further information on the use of the F34NTA22-S2/S3/S5/S6 cables, see the [article](#).

